

1967 NC 69, Hayesville NC 28904. (704) 796-3502

## Installation instructions 99-04 wj grand cherokee bolt on coil repair kit. Tools Needed:

- 1" step drill and 3/8" drill bits.
- Hand drill.
- Angle grinder.
- Steel hammer and soft dead blow hammer
- Socket set and wrenches.
- Angle grinder.
- Alan wrenches.
- Common sense and patience.
- 1. Don't be dumb, If you do not know how to install parts and have no proper assistance from an experienced mechanic please have this installed by a professional.
- 2. Properly support the front of the chassis on jack stands as well as the front axle just enough that the tires are off the ground. Remove front driver side wheel.
- 3. Using an angle grinder, grind rusted parts down to a smooth flat working surface. (Both sides)
- 4. Hold the new coil center and align it with the OE isolator retainer hole. Use a clamp or a ½" bolt to hold the coil center in place.
- 5. Using a 3/8 drill and the coil center as a guide drill the 7 holes into the coil bracket. (both sides)

- 6. Using a 1" step drill, drill a 1" hole into the side of the factory coil mount closest the front of the steering knuckle. This will allow access for a 9/16" wrench to hold the flange nuts to retain the coil center.
- 7. Using the 3/8 flat head socket screws and flange nuts, tighten down all possible nuts and bolts to a good firm tightness.
- 8. re assemble vehicle to factory specifications.